

Table: Interface and global level LLDP modes

Interface Level LLDP mode	Global Level LLDP mode			
	NONE	TRANSMITTER	RECEIVER	TRANSCEIVER
NONE	NONE	NONE	NONE	NONE
TRANSMITTER	NONE	TRANSMITTER	NONE	TRANSMITTER
RECEIVER	NONE	NONE	RECEIVER	RECEIVER
TRANSCEIVER	NONE	TRANSMITTER	RECEIVER	TRANSCEIVER