

Quick Access Links




New password for appliances

The appliance and LOM passwords are set to the Citrix serial number, which is displayed on the rear of appliance. For more information, see [Initial Configuration](#).

Unpacking the Package

The Citrix ADC platform package includes a hardcopy of the End User License Agreement (EULA) and the Licensing Document. For unpacking the appliance package, see the sample [video](#).



Installing the Hardware

For information about how to install the hardware, see [Installing the hardware](#).

After Installation

After installing the hardware, perform the initial configuration of the SDX appliance and then configure the Citrix ADC features, that meet your requirement. For details, see [Citrix ADC SDX](#) and [Citrix ADC documentation](#).



Citrix SDX 15xxx 50G Platform

For information about the Citrix SDX 15xxx 50G platform, see [Citrix SDX 15xxx 50G](#).

Data Sheets

To view the data sheets of the hardware models, see [Citrix ADC Data Sheets](#).



Product Documentation

To view the complete hardware documentation, see [Citrix ADC Hardware Platforms](#).